

EUV Lithography

Patrick Naulleau


Center for X-ray Optics, Lawrence Berkeley National Laboratory



Outline

- Introduction
- Review of key optics concepts for lithography
- EUV Capabilities/Challenges
- EUV patterning and resists
- Mask defects and printing


EUV: extension of optical lithography



© Patrick Naulleau, 2008

3

The mask serves as the circuit master in lithography systems



© Patrick Naulleau, 2008

4


Review of key optics concepts for lithography

- Diffraction
 - Resolution
 - Depth of focus
- Partial coherence
- Etendue

© Patrick Naulleau, 2008

5

Diffraction




Angular spread, $\theta = \text{asin}(\lambda/W)$

© Patrick Naulleau, 2008

6

Image formation: inverse diffraction

- Function of lens is to invert diffraction process
 - $\theta = \text{asin}(\lambda/W) \Rightarrow W_{\min} = \lambda/\sin(\theta_{\max})$




© Patrick Naulleau, 2008

7

Depth of focus

- Let DOF be proportional to distance where single-sided blur = resolution




© Patrick Naulleau, 2008

8

Concept of partial coherence factor (σ)


- Most fundamentally, σ is the ratio of mask-side resolution limit to coherence width (W_c)
- Large W_c = small σ
- Determines area over which object components add coherently



© Patrick Naulleau, 2008

9

Critical illumination: $\sigma = \text{ratio of NAs}$



$$W_c \propto 1/NA_{ci}$$


$$Res_o \propto 1/NA_{po}$$

$$\sigma = Res_o/W_c = NA_{ci}/NA_{po}$$

© Patrick Naulleau, 2008

10


Pupil fill: alternative view of σ



© Patrick Naulleau, 2008

11

Etendue: space-bandwidth product




- The optic etendue (maximum accepted space-bandwidth product) is
 - Field of view area X acceptance solid angle
 - $6 \times 96 \times 0.01 \text{ mm}^2 \text{ sr} \sim 7 \text{ mm}^2 \text{ sr}$

© Patrick Naulleau, 2008

12

Projection optics etendue limits usable source etendue and thus power




- A 1 mm source with 45-degree collection would have an etendue of ~2 mm² sr (min $\sigma = 0.53$)
- A 0.1 mm source with 70-degree collection would have an etendue of ~0.04 mm² sr (min $\sigma = 0.08$)

© Patrick Naulleau, 2008


13

Increasing NA demands more mirrors

NA = 0.1
4 mirrors



- More mirrors means lower throughput
- But, larger NA means larger etendue



© Patrick Naulleau, 2008

14













EUV Patterning Capabilities: modeling

© Patrick Naulleau, 2008

15

Extendibility of EUV

Binary amplitude mask, $\sigma = 0.7$, no OPC, no bias correction


	45 nm	32 nm	22 nm	16 nm	13 nm
0.25 NA					
0.35 NA					
0.5 NA					

© Patrick Naulleau, 2008

16

Optical transfer function vs NA

Binary amplitude mask, $\sigma = 0.5$, no aberrations




© Patrick Naulleau, 2008

17

Optical transfer function through sigma

Binary amplitude mask, NA = 0.32, no aberrations




© Patrick Naulleau, 2008

18

Optical transfer function through illumination type

Binary amplitude mask, NA = 0.32, no aberrations





© Patrick Naulleau, 2008

19

8-nm possible at 0.5 NA with conventional mask

Binary amplitude mask, dipole illumination, no OPC, no bias correction

Pole radius = 0.2
Pole offset = 0.8



© Patrick Naulleau, 2008

20

EUV-specific challenges

Challenge	Consequence
EUV radiation is not transmitted through the atmosphere	Tool must operate in vacuum environment
All solid materials strongly absorb EUV radiation	Refractive optics not possible. Use only reflective mirrors & reticles
Hydrocarbons & water vapour are cracked by EUV, contaminating mirror surfaces – C deposition & oxidation of coatings	Minimize hydrocarbons and water vapour content in the tool. Needs cleanliness of ultra high vacuum (UHV)
Source chamber cannot be physically separated from imaging optics chamber	Contain any debris produced by source – particles & ions
EUV sources are inefficient producers of radiation	Efficient thermal management of waste heat from high input powers required
Vacuum clamping cannot be used. Air-bearing motion mechanisms are complex	Use electrostatic clamping, mag. Lev. stages
Tilted mask plane: system not telecentric at reticle	Strict reticle flatness requirements
Tilted mask plane: shadowing by 3D mask structure	Position dependent mask bias correction required
Short wavelength -> high scatter -> large position dependent flare	Long-range “proximity” correction required
Reflective mask leads to potential “buried” phase defects (< 3-nm tall)	Extremely high sensitivity mask blank inspection required

© Patrick Naulleau, 2008

21

EUVL critical issue list

Top 3 Critical Issues

- 1. Reliable high-power source and collector module**
 - Largely industrial effort
- 2. Availability of defect-free masks and mask infrastructure**
- 3. Resist resolution, sensitivity & Line Edge Roughness (LER) met simultaneously**


Ref: 2008 International EUVL Steering Committee

© Patrick Naulleau, 2008

22

Berkeley EUV Nano-patterning tool designed to support advanced EUV research

- Numerical aperture = 0.3
- Spatial resolution = 12 nm*
- Supports approximately 200 user shifts per year with nearly 100% uptime
- Unique programmable coherence illuminator enables world's finest projection EUV resolution
- Supports:
 - Resist development
 - Mask development
 - Mask defect studies



© Patrick Naulleau, 2008


Worldwide user base including industry, academia, and research institutes



© Patrick Naulleau, 2008


24

Simultaneously meeting resolution, sensitivity, and LER crucial issue for EUV resists




32-nm half pitch (21-nm iso) - 2013*
 22-nm half pitch (15-nm iso) - 2016
 16-nm half pitch (11-nm iso) - 2019

All three requirements must be met and balanced for any technology or it will not work



1.2 nm
 0.8 nm
 0.6 nm



10 mJ/cm²
 10 mJ/cm²
 10 mJ/cm²

LER: Line Edge Roughness

* 2007 ITRS Roadmap

© Patrick Naulleau, 2008

25


Although most EUV resists are based on 193 or 248 nm systems, EUV interaction with resist these materials is fundamentally different

- EUV energy (92 eV) many times higher than Photo Acid Generator (PAG) activation energy
- EUV interacts with all atoms, cannot be made to preferentially interact with PAG
- Photons do not directly activate PAG but rather generate secondary electrons upon interaction with first encountered atom
 - Secondary electrons eventually activate PAG


© Patrick Naulleau, 2008

26

Although most EUV resists are based on 193 or 248 nm systems, EUV interaction with resist these materials is fundamentally different




Chemically amplified resists now approaching 20 nm




High pattern fidelity at small feature sizes


24 nm HP





22 nm HP



20 nm HP



30 nm 1:1 contacts



Resist D, film thickness = 50 nm

© Patrick Naulleau, 2008


29

Rinse agents for LER reduction without resolution or sensitivity trade-offs




Berkeley MET

XP5494-C
resist,
Y-Monopole



Baseline Process

CD = 41.7 +/- 0.8 nm
LER = 4.3 +/- 0.4 nm



Rinse Agent Process

CD = 40.6 +/- 0.6 nm
LER = 3.2 +/- 0.4 nm

- Rinse agent applied instead of water after development
- ~1-nm reduction in LER observed
- No effect on resolution or sensitivity


Data courtesy of Tom Wallow,

© Patrick Naulleau, 2008

30



Repeated printing of 35 nm contacts shows variation NOT dominated by photon noise




© Patrick Naulleau, 2008

31



Optical mask error enhancement factor (MEEF) does not explain observed contact variation




© Patrick Naulleau, 2008

32

Modeling Resist Using Simple Point-Spread-Function (PSF) Method

- PSF resist modeling* is fast and convenient
- Model easily generated
- Provides intuitive link to resist resolution limit
- Few parameters makes model less susceptible to extrapolation errors
- Resist process well approximated by deprotection function**

“Deprotection blur” function PSF




* C. Ahn, H. Kim, K. Baik, “A novel approximate model for resist process,” Proc. SPIE **3334**, (1998).

** Gregg Gallatin, “Resist Blur and Line Edge Roughness,” Proc. SPIE 5754, (2005)

© Patrick Naulleau, 2008

33


Resist blur dominates MEEF



© Patrick Naulleau, 2008

34


Resist blur dominates MEEF



© Patrick Naulleau, 2008

35

The mask serves as the circuit master in lithography systems




© Patrick Naulleau, 2008


36

Pattern defects on become replicated problems on the wafer, although attenuated by optic and resist

Mask: 60-nm defect



Resist: 9% CD Change




Data courtesy of Ted Liang, Intel
Details published at Photomask Japan, 2006

© Patrick Naulleau, 2008



37



Buried (phase) defects become intensity after band-limited imaging and further enhanced by defocus




Modeled aerial image of programmed 100-nm isolated defects through focus (100-nm steps)
100-nm defects not expected to be printable at Esize)



© Patrick Naulleau, 2008

38

Programmed “buried” defects developed to study critical mask issues



The world's highest-performance EUV microscope dedicated to photomask research


See poster

ALS BL 11.3.2
illumination window
mask
off-axis ZP (μscope objective)
CCD


NA = real-time selectable
 0.25–0.35 (4x)
Res. ≥ 93 nm (23 @ 4x)
Mag = 800–1000x

- International EUV program's primary tool for at wavelength mask defect inspection and cross correlation with complimentary techniques
- Spatial resolution approaching 90 nm at the mask (23 at wafer)
- Working with partners regarding future upgrades. Special attention to supporting the development of commercial tools.

Ken Goldberg / KAGoldberg@lbl.gov
 © Patrick Naulleau, 2008



Implications of etendue limits for mask inspection microscopy



- A 1 mm source with 45-degree collection would have an etendue of ~2 mm² sr (min σ = 0.53)
- A 0.1 mm source with 70-degree collection would have an etendue of ~0.04 mm² sr (min σ = 0.08)