



### Fully Automatic In-Feed Surface Grinder

# DFG8540/8560

## Advanced thinning power for large wafers

#### **Grinder of choice**

The DFG8540/8560 improves upon the functionality and performance that made the DISCO 800 series the grinder of choice at facilities around the world.

#### Thin grinding (<100 µm)

Advanced handling systems and design features facilitate high yield for thin wafer grinding.

#### **Design flexibility**

The DFG8540/8560 can be integrated with DISCO's Dicing Before Grinding (DBG) system as well as polishers (DFP8140/8160) for in-line processing solutions.



שנסטע

#### Improved grinding quality

Through innovations in equipment design, both spindles now grind wafers at the same relative position. This improves single wafer thickness variation as well as wafer to wafer thickness variation.


#### **Backward-compatibility**

Supports the same proven technology of DISCO's 800-series grinding wheels, spindles, chuck tables and dresser boards.

#### Easy operation

The DFG8540/8560 utilizes an LCD to screen graphical user interface, maki operation and maintenance intuitive a easy.





LCD touch screen





Safe wafer handling with the thin wafer robot pick

## Fully Automatic In-Feed Surface Grinder DFG8540/8560



Specifications					
Specification			Unit	DFG8540	DFG8560
Wafer diameter			-	φ 8" (φ 4"/5"/6"/8")	φ 300 (φ 200/φ 300)
Grinding method			-	In-feed grinding with wafer Rotation	
Griding wheels			mm	φ 200(φ 8") Diamond wheel	φ 300 Diamond wheel
	Rated output		kW	4.2	4.8
Spindle	Rated torque range		min <sup>-1</sup>	1,000 ~ 7,000	1,000 ~ 4,000
Grinding Accuracy	BG	Thickness variation within one wafer Thickness	μm	1.5 or less (with dedicated chuck table)	3.0 or less (with dedicated chuck table, φ 300mm wafer)
		variation between wafers	μm	±3.0 or less	
		Finished surface roughness	μm	Ry 0.13(with #2000 finish) Ry 0.15(with #1400 finish)	
Machine dimensions(WxDxH)			mm	1,200 × 2,670 × 1,800	1,400 × 3,322 × 1,800
Machine weight			kg	Approx.3,100	Approx.4,000

#### **Environmental conditions**

- Use clean, oil-free air at a dew point of -15  $^{\circ}$ C or less. (Use a residual oil: 0.1 ppm. Filtration ratinzg: 0.01  $\mu$ m/99.5 % or more).
- Keep room temperature fluctuations within  $\pm 1$  °C of the set value. (Set value should be between 20 25 °C).
- Keep grinding water and cleaning water + 0 2 °C above room temperature (fluctuations within 1 °C over one hour).
- $\bullet$  Keep spindle cooling water temperature between 20 25  $^{\circ}\! C$  (fluctuations within 2  $^{\circ}\! C$  over an hour).
- The machines should be used in an environment, free from external vibration. Do not install machine near a ventilation opening, heat generation equipment or oil mist generating parts.
- This machine uses water. In case of water leakage, please install the machine on the floor with sufficient waterproofing and drainage treatments.
- \* All the pressures are described using gauge pressure.
- \* The above specifications may change due to technical modifications. Please confirm when placing your order.
- \* For further information please contact your local sales representatives.

