



Defining Industrial Applications of Accelerators?

- ❑ Generally, high energy particle beams induce nuclear reactions and activation
- ❑ In contrast, in industrial applications, nuclear reactions and activation are undesirable and avoided, but other effects of ionizing radiations are searched for
- ❑ These desired effects include:
 - Sterilization
 - Cross linking of polymers
 - Curing of composite materials
 - Modification of crystals
 - Improvement of semi conductors
 - Beam aided chemical reactions


What beams are used?

- The choice of particle beams used in industrial applications is defined, to a large extent, by the desire to avoid nuclear reactions and activation.
- Commonly used beams include:
 - Electron beams below 10MeV.
 - X-Rays from e-beams below 7.5MeV.
 - Intense, low energy proton beams.
 - Low energy heavy ion beams (well below the Coulomb barrier).
- Also, for industrial applications, large beam currents/powers are needed to reach industrial scale production rates. Beam powers from 50 kW to 1 MW are common.




Key E-beam and X-ray Industrial Applications

- **Sterilization**
 - Sterilization of Medical Devices
 - Surface Sterilization
 - Food Pasteurization
- **E-beam induced chemistry**
 - Cross linking of Polymers
 - Curing of composites
 - Environment remediation
- **E-Beam induced crystal defects**
 - Improvement of Semiconductors
 - Coloring of Gemstones
- **Cargo screening**







IBA Industrial's Product Portfolio

<p>Dynamitron 0.5 -> 5 MeV 160 mA Electron beam</p>  <p>Main application E-beam Crosslinking</p>	<p>Rhodotron 3 -> 10 MeV 42 mA 420 kW Electron beam and X-rays</p>  <p>Main application E-beam box sterilization</p>	<p>eXelis 5 – 7 MeV 80 mA 560kW X-rays</p>  <p>Main application X-ray pallet sterilization</p>
--	---	---

Linac's reach about 40-60 kW

Protect, Enhance, and Save Lives





2. INDUSTRIAL E-BEAM ACCELERATORS: THE RHODOTRON

Brief explanation of the Rhodotron:


A short history



- 1989: First design by Pottier at French Atomic Energy Agency (CEA) → Patent for 20 yrs
- 1990: Prototype by CEA, at 3.5 MeV and 20 kW
- 1991: IBA/CEA collaboration gave IBA exclusive rights to industrialize the Rhodotron
- 1991-1994: First industrial unit designed: 5 & 10 MeV with CW power up to 100 kW
- 1995: First sale of a Rhodotron (Studer)
- 2012: First X-Ray TT 1000 in operation (Studer too) !
- 2015: Different models available (TT100-200/300-1000)

Brief explanation of the Rhodotron:

The main components




RF Cavity
E-Gun
Magnets
Final Power Amplifier
RF tube (Tetrode)
Vacuum system

Protect, Enhance, and Save Lives

iba

Brief explanation of the Rhodotron:

Basic acceleration and re-circulation



Electrons are generated by the e-gun, then accelerated by the electric field in the cavity:

$$\Delta E_c = F \cdot x = q \cdot E \cdot x = q \cdot \frac{V}{x} \cdot x$$

After the first acceleration pass, the electron path is curved by a magnetic field:

$$F = q \cdot (E + v \cdot B) = \frac{m \cdot v^2}{r} \Rightarrow B \cdot r = \frac{m}{q} \cdot v$$

Important: electrons are relativistic after first pass: $v = \text{constant}$!

E (e ⁻)	50keV	1MeV	10MeV
β	0.41	0.94	0.99
γ	1.098	2.956	20.56


Protect, Enhance, and Save Lives

- 10 -

The Rhodotron: Basic acceleration and re-circulation

time in $[0, T/4]$


- Electric field outward facing
- Electrons injected and travel first half crossing



The Rhodotron: Basic acceleration and re-circulation

time in $[T/4, T/2]$


- Electrons cross inner cylinder holes (pillar)
- Electric field polarity reversing



The Rhodotron: Basic acceleration and circulation

time in $[T/2, 3T/4]$


- Electric field inwards facing
- Electrons complete 2nd half of first crossing



The Rhodotron: Basic acceleration and circulation


time in $[3T/4, T]$

- Electrons deflected back into the cavity
- Electric field polarity reversing



The Rhodotron: Cavity Design

Introduction to Rhodotrons e-beam accelerators



Electric (\vec{E}) and magnetic (\vec{B}) fields in Rhodotron coaxial cavity

- ① RF sinusoidal electrical field \rightarrow coaxial cavity !
 - ② Frequency is 107 MHz (215 MHz for TT100). Depends on tube availability \rightarrow best is FM band
 - The size of the cavity is fixed by f:
 - Height = 0.5λ
 - Radius ideal is 0.35λ to allow transit in magnets
 - Fundamental mode (TEM 1):
 - Radial E-field and azimuthal B-field
 - E-field varies as $\cos(z) / r$
 - Electrical losses increase with $f^{1/2}$
 - Cost increase with size, small is complicated for beam optics: phase acceptance & transmission
- \rightarrow **Maximize energy gain vs losses & cost !**


Protect, Enhance, and Save Lives

- 15 -

iba

The Rhodotron: Cavity Design

Introduction to Rhodotrons e-beam accelerators



- **Interesting design notes:**
 - 70 kW to polarize the cavity, 5000 Amps in the walls
 - Electrical field is max in the median plane and Magnetic field is max at top and bottom \rightarrow Easy magnetic coupling
 - Rounded cavity's bottom is to reduce RF power and shift secondary modes
 - Total flight of the electrons is ca. 28 meters
 - Beam can be extracted at each magnet
 - Cavity holes and space charge are critical
 - **First pass is the most critical because of beam low energy (50 keV to 1 MeV)!**

Protect, Enhance, and Save Lives

- 16 -

iba

Transverse focusing in the Rhodotron

- From the RF-fields
 - Electric \Rightarrow holes in the cavity walls
 - Magnetic \Rightarrow Perpendicular to the radially directed cavity passes
 - Note that the B and E-fields are 90° out of phase
- From the bend magnets
 - Pole face angles are chosen such as to provide weak horizontal and vertical focusing





Figure 3.7 : Effet alternativement focalisant et défocalisant du champ magnétique.

Protect, Enhance, and Save Lives

- 17 -

The Rhodotron: E-gun

Introduction to Rhodotrons e-beam accelerators



E-Gun Design:


- Low work function heated flat cathode with modulation grid
- Extraction at 40 kV
- Neg. Bias grid
- Driven by RF to avoid beam losses (pick up)
- Capture during 1.5ns (60° of phase)
- Peak current: 1A

Protect, Enhance,

iba

The Rhodotron: deflection magnets

Introduction to Rhodotrons e-beam accelerators




• Magnet Design:

- Simple dipoles with adjusted pole face angles
- Fringe field has a strong impact on transmission
- Magnets are different for TT100, TT200, TT300 and T1000 to increase max current
- TT1000 has acromatic magnet 1 to increase max current to 100 mA: increase phase acceptance, control beam size and reduce fringe field

iba

The Rhodotron: RF Chain & Final Power Amplifier


Introduction to Rhodotrons e-beam accelerators



• How to polarize the cavity at 680kV and 107 MHz ?

- Cavity is a resonator ($Q > 40000$)
- Signal is created in the Low Level Rack (LLRF) and transmitted to the cavity through RF chain
- From 1W in LL-rack to 280kW in the cavity
- Phase is controlled and adjusted
- Power is coupled to cavity with a coupling loop in the coupler



iba



Transport line, Scanning, Horn

Goal of the BTL and horn ?

- Transport beam from Rhodo vault to target without any losses
- Scan the beam across the material to be treated according to conveyor speed
- Convert electrons to X-ray when needed

Dynamitron

Generalities

- Electron or proton beam, up to 160 mA of beam current
- Energy range : 500 keV to 5 MeV
- Applications - electron:
 - Cable insulation cross-linking
 - Sterilization (medical devices)
 - Improvement of the color of glass and gemstones
 - Electronic pasteurization
 - ...
- Applications - proton:
 - Photovoltaic silicon wafer slicing
 - Cancer treatment by Boron Neutron Capture Therapy (project)
 - ...




INDUSTRIAL UNVEILED

- 23 -

Iba

Dynamitron

High Voltage generation => similar to a Cockcroft-Walton



INDUSTRIAL UNVEILED


- 24 -

Iba

Dynamitron


Electron beam generation

- Parallel fed cascade voltage multiplier
- Accelerated from voltage drop from High Voltage (up to 5 MV DC) to ground.
- Beam in a long acceleration tube under ultra high vacuum (10e-8 mbar range)
- Beam = LVR – (BTD + HVD + CNA)



INDUSTRIAL UNVEILED

- 25 -




Iba

Dynamitron


Main components



Power oscillator



RF transformer



Dome

Dees and rectifier stack


INDUSTRIAL UNVEILED

- 26 -


Iba

Dynamitron

Main components



Electron gun



Beam tube



Scan Horn

INDUSTRIAL UNVEILED


- 27 -

Iba

Dynamitron

Beam regulation – How to heat up the filament ?

- VFMG (Variable Frequency Motor Generator) to generate filament power at High Voltage terminal
- Filament heating voltage is generated by a variable frequency motor generator
 - Motor is at ground level
 - Insulated shaft to hold the high voltage
 - Generator in high voltage terminal



INDUSTRIAL UNVEILED

- 28 -

Iba

Dynamitron

Electron beam generation



VFMG shaft

Beam Tube



INDUSTRIAL UNVEILED

- 29 -

Iba

Some Dynamitrons...

Easy-E-Beam

- Self Shielded
- Compact
- Right angle
- 800 kV
- 100 mA




INDUSTRIAL UNVEILED

- 30 -

Iba

High power E-beam accelerators => the Linacs



Protect, Enhance, and Save Lives

- 31 -

Iba

High power E-beam accelerators: 1) the Rhodotron



Typical applications:

- Modification of polymers
- Sterilization of medical devices
- Preservation of foods
- Treatment of waste materials
- Gemstones and semiconductors


Protect, Enhance, and Save Lives

- 32 -

Iba

The Rhodotron: Other sub-systems : Bill of Material

Introduction to Rhodotrons e-beam accelerators



RF Cavity

E-Gun

Magnets

Final Power Amplifier

Vacuum system

RF Tube (Tetrode)

Cooling & pneumatic system

Beam Transport line

Power Supply Room

Horns & Targets

iba

Wrap up: The Rhodotron models & performance

Introduction to Rhodotrons e-beam accelerators



TT100

3 to 10 MeV

1m cavity

0.83 MeV/Pass

Beam < 40kW



TT200/T300

3 to 10 MeV

2m cavity

1.0 MeV/Pass

Beam < 190kW



TT1000

3 to 7 MeV

2m cavity

1.2 MeV/Pass

Beam < 630kW

Protect, Enhance, and Save Lives

- 34 -

iba

Options for the sterilization of medical devices

- ❑ Steam (incompatible with most polymers)
- ❑ Ethylene Oxide
 - Inexpensive
 - EtO is explosive, toxic and harmful to the environment
 - EtO sterilization may leave harmful residues
- ❑ Irradiation
 - Cobalt
 - E-beam
 - X-ray



35 Protect, Enhance, and Save Lives

- 35 -

The options for sterilization by irradiation (1)

- ❑ **Gammas from Co60** ($T_{1/2}=5.2$ y; $\gamma_1=1.33$ MeV; $\gamma_2=1.17$ MeV)
 - Low investment cost, specially for low capacities
 - Simple and reliable, scalable from 100 kCuries to 6 MCuries (about 5 kg of Co-60)
 - Isotropic radiation > inefficiencies in use
 - Pallet irradiation, but low dose rate > slow process
 - Absolutely no activation
 - Cannot be turned OFF > inefficient if not used 24/7
 - Growing security concern: the cobalt from a sterilization plant could be used to make dirty bombs

36 Protect, Enhance, and Save Lives

- 36 -

Iba

The options for sterilization by irradiation (2)

□ Electron beams

- Directed radiation > Efficient use
- Lowest cost of sterilization for large capacities
- Can be turned OFF > safer
- Short range (4.5 g/cm² at 10 MeV) > 2-sided irradiation of boxes
- More complex dose mapping
- Minimal, hardly measurable, but non zero activation

37

Protect, Enhance, and Save Lives

- 37 -

Iba

The options for sterilization by irradiation (3)

□ X-Rays from E-beams

- Excellent penetration
- Simple dose mapping
- Pallet irradiation
- Directed radiation > Efficient use
- Loss of a factor 10 in energy when converting e-beams to photons
- Cost of sterilization higher than electrons
- Cost of sterilization is generally higher by X-Rays than Cobalt if used 24/7, excepted for very large capacities
- Can be turned OFF > safer
- Minimal, hardly measurable, but non zero activation

38

Protect, Enhance, and Save Lives

- 38 -

Iba

Food irradiation applications

Low Dose Applications (< 1kGy)

- **Phytosanitary** Insect Disinfection for grains, papayas, mangoes, avocados...
- **Sprouting Inhibition** for potatoes, onions, garlic...
- **Delaying of Maturation**, parasite disinfection.



Medium Dose Applications (1 – 10 kGy)

- **Control of Foodborne Pathogens** for beef, eggs, crab-meat, oysters...
- **Shelf-life Extension** for chicken and pork, low fat fish, strawberries, carrots, mushrooms, papayas...
- **Spice Irradiation**



High Dose Applications (> 10 kGy)

- **Food sterilization** of meat, poultry and some seafood is typically required for hospitalized patients or astronauts.



39 Protect, Enhance, and Save Lives

- 39 -

Iba

E beam treatment of Tires

- Reduction in material hence in the weight of the tire
- Relatively low cost synthetic rubber can be used instead of costly natural rubber without a loss in strength
- The radiation pre-vulcanization of body ply is achieved by simply passing the body ply sheet under the scan horn of an electron accelerator to expose the sheet to high-energy electrons
- Higher production rates
- Construction of green tires
- Reduction of production defects




40 Protect, Enhance, and Save Lives

- 40 -

Iba

Polymer Cross-Linking

- **Wires** stand higher temperature after irradiation
- **Pipes** for central heating and plumbing
- **Heatshrink elastomers** are given a memory




41 Protect, Enhance, and Save Lives

- 41 -


Composite curing: X-ray Cured Carbon Fiber

- Sports Car Fender made light, resistant and requiring less fuel



42 Protect, Enhance, and

E-beam irradiation improves SC switching speed



Typical semiconductors:

- fast recovery diodes
- power diodes
- Bipolar power transistors
- power MOSFETs
- power rectifiers
- IGBT's
- thyristors
- silicon-controlled rectifiers


43 Protect, Enhance, and Save Lives

- 43 -

Iba

Microfiltration membranes by heavy ions

- Heavy ion beams are used to produce track-etched microfiltration membranes, commercialized i.a. under the brand name "Cyclopore"
- In these membranes, tracks of slow, heavy ions crossing a sheet of polymer are chemically etched, giving cylindrical pores of very accurate diameter



44 Protect, Enhance, and Save Lives

- 44 -

Iba


Beam delivery options 1/3 : Rhodotron E-beam

1

Rhodotron E-beam
10 MeV E-beam
Boxes



eXelis
5 or 7 MeV X-ray
Pallets



Rhodotron Duo
10 MeV E-beam
+ 5 or 7 MeV X-ray
Boxes




INDUSTRIAL UNVEILED

- 45 -

iba

Rhodotron 10 MeV E-beam



<http://www.iba-sterilization.com/rhodotron-e-beam-sterilization-solution>

Protect, Enhance, and Save Lives

- 46 -

iba

Beam delivery options 1/3 : Rhodotron E-beam

Rhodotron E-beam


10 MeV E-beam
Boxes



2

eXelis

5 or 7 MeV X-ray
Pallets



Rhodotron Duo

10 MeV E-beam
+ 5 or 7 MeV X-ray
Boxes




INDUSTRIAL UNVEILED

- 47 -


iba

Irradiation Processing Comparison


E-beam



X-ray



Gamma



Key differences


- Source: electricity vs Cobalt-60
- Directive vs Isotropic
- Switch on/off vs continuous radiation

INDUSTRIAL UNVEILED

- 48 -

iba

Irradiation Penetration Properties



Deeper **Penetration**
 -> Bigger **Packaging**
 -> Better **Quality**

INDUSTRIAL UNVEILED

- 49 -


iba

Beam delivery options 1/3 : Rhodotron E-beam

Rhodotron E-beam
 10 MeV E-beam
 Boxes



eXelis
 5 or 7 MeV X-ray
 Pallets



3

Rhodotron Duo
 10 MeV E-beam
 + 5 or 7 MeV X-ray
 Boxes




INDUSTRIAL UNVEILED

- 50 -

iba

Rhodotron DUO

One irradiation, one conveyor, two technologies



- **Rhodotron DUO**
 - One accelerator
 - One conveyor
 - Two technologies
- **E-beam**
 - Beam overlapping
 - Double side
- **X-ray**
 - Product overlapping
 - Multipass processing

Protect, Enhance, and Save Lives

- 51 -

Iba

Rhodotron DUO – E-beam mode



INDUSTRIAL UNVEILED

- 52 -

Iba

Rhodotron DUO – X-ray mode



INDUSTRIAL UNVEILED

- 53 -

Iba

The Industrial Business needs ?

The dream machine

- **Electron beam accelerator with:**
 - Fixed energy between 800 keV and 10 MeV (versatility with multiple BTLs)
 - Low energy dispersion (few %)
 - Fast beam current control for accurate dose control
 - Continuous beam for scanning and higher throughput
 - High electron beam power for X-ray generation (up to 700 kW)
 - High efficiency for lower energy footprint (> 35%, Linacs < 20%)
 - High robustness, high up time, easy tuning and maintenance
 - Low cost

↳ **Perfect competitor to Linacs !**

INDUSTRIAL UNVEILED

- 54 -


Iba

Dynamitron

Working Principles

Water tower
analogy

No enough
pressure to water
an unreachable
flower






Dynamitron



Working Principles


Water tower
analogy



We invent a
pressure
multiplication
device !!











Some Dynamitron ...

BGS 5 MeV




INDUSTRIAL UNVEILED

- 65 -

Some Dynamitron...

BGS - 5 MeV

- 5 MeV
- 50 mA
- 500 kW
- In line



INDUSTRIAL UNVEILED

- 66 -

Iba

Some Dynamitron projects

Yagami – How to make a protons out of a Dynamitron

1. Reverse polarity
2. Make the dome bigger
3. Replace the simple filament by a complex ion source system ☺




INDUSTRIAL UNVEILED

- 67 -

Iba

Some Dynamitron projects

Sigen



INDUSTRIAL UNVEILED

- 68 -

Iba